# iHome Wireless Keyboard & Laser Mouse for Mac Noteboks

## IH-K241LS

## Product Knowledge Base

**Frequently Asked Questions (FAQs)**

### 1. What are the Features?

- Plug-n-Play no syncing needed
- 2.4 GHz wireless frequency up to 30 feet
- Quick launch hot keys & media controls
- One touch keys launch iTunes iChat Safari iCal & more
- Function keys offer access to Dashboard Expose and media controls
- Keyboard built-in scroll wheel
- Scissor type notebook keycaps
- Keyboard & mouse LED low battery indicators
- High resolution laser mouse
- Stowable USB nano receiver
- Power saving On/Off switch

**2. What is included in the box?**

- Wireless keyboard
- Wireless laser mouse
- USB nano receiver
- 3 AA Energizer batteries
- Installation CD
- User manual
- Quick start guide

**3. What are the system requirements?**

**Mac**

- OS X 10.5 or later
- USB Port
- CD-ROM Drive

**4. Where can I download the latest driver?**

Visit www.life-works.com/drivers

**5. Where can I find warranty information?**

Visit www.life-works.com/warranty

**6. How to install the software?**

- Insert installation CD
- Double-click iHome Keyboard icon the installation software will open.
- when Welcome screen displays, click **Continue**
- Click **Install** to install driver in default location
- Type your password if asked to do so
- When prompted, click **Continue Installation**
- Click **Continue** again
- Click **Restart** to restart your computer

**7. How to use the mouse?**

- Roll the wheel up and down to **scroll vertically**. Tilt the wheel left or right to **scroll horizontally.**

**8. How to use your keyboard?**

- Use the built-in scroll wheel to scroll through documents, emails, web pages, and so on, without using your mouse.

## function keys

| function key | function |
|---|---|
| F1 | decrease brightness |
| F2 | increase brightness |
| F3 | Exposé® |
| F4 | Dashboard |
| F6 | sleep |

## media keys

| media key | function |
|---|---|
| F7 | previous track (hold for rewind) |
| F8 | play/pause |
| F9 | next track (hold for fast forward) |
| F10 | mute |
| F11 | volume down |
| F12 | volume up |

## quick launch application keys

| application key | function |
|---|---|
| | iTunes® |
| | Mail |
| | iChat® |
| | Safari® |
| | iCal® |
| | Front Row |

# Troubleshooting

1. **Mac application keys do not launch?**

    - Reinstall the driver
    - Ensure that the application you want to launch is in the application folder.

2. **Keyboard or mouse low battery indicator (red light) flashing?**

    - Install  batteries

3. **Keyboard or mouse does not work?**

    - Ensure the USB nano receiver is connected
    - Connect the USB nano receiver to a different port
    - Check that the batteries are inserted correctly.
    - Move the mouse closer to the USB nano receiver.
    - Ensure the laser sensor on the bottom of the mouse is clean.
    - Install fresh batteries.

## Product Operating Tips

- Your mouse will operate from as far away as 30 ft. (10 m) from your computer.
- To save battery power, turn off the mouse when not in use.
- Store the nano USB receiver under the battery cover for travel or when not in use.

## Technical Support

For questions regarding your iHome computer accessory, please visit our website at www.life-works.com or call **1-877-Life-540/ 1-877-543-3540.**
2009 © LifeWorks Technology Group LLC.
iHome™ is a trademark of SDI Technologies Inc. used under license.
Mac® is a trademark of Apple Inc., registered in the U.S. and other countries.
All other brands and logos are trademarks of their respective companies.